

ICC-Profil Einstellungen / ICC Profile Settings

Epson Expression Photo XP-65		Papiere Epson (3)		
Papier / Paper	Tinte / Ink	Medientyp / Media Type	Qualität / Quality	Profil / Profile
Epson Archival Matte Paper	Coloration ED2	Epson Matte	Quality	24XL_ED2_EpArchivalMatte.icc
Epson Premium Glossy	Coloration ED2	Epson Premium Glossy	Best Quality	24XL_ED2_EpPremGlossy.icc
Epson Premium Semigloss	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_ED2_EpPremSemigloss.icc
In den Druckertreiber-Einstellungen die Option "Schweres Papier und Briefumschläge" mit der Einstellung "EIN" dauerhaft aktivieren.				