

ICC-Profil Einstellungen / ICC Profile Settings

Epson Expression Photo XP-65		Papiere Hahnemühle (7)		
Papier / Paper	Tinte / Ink	Medientyp / Media Type	Qualität / Quality	Profil / Profile
Photo Matt Fibre 200	Coloration ED2	Epson Matte	Quality	24XL_ED2_HMPhMattFibre.icc
Photo Matt Fibre Duo 210	Coloration ED2	Epson Matte	Quality	24XL_ED2_HMPhMattFibreDuo.icc
Photo Glossy 260	Coloration ED2	Epson Premium Glossy	Best Quality	24XL_ED2_HMPhotoGlossy.icc
Photo Luster 260 / 290	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_ED2_HMPhotoLuster.icc
Photo Pearl 310	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_ED2_HMPhotoPearl.icc
Sustainable Photo Satin	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_ED2_HMSustainablePhSat.icc
Photo Silk Baryta X	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_ED2_HMPhoSilkBarytaX.icc
In den Druckertreiber-Einstellungen die Option "Schweres Papier und Briefumschläge" mit der Einstellung "EIN" dauerhaft aktivieren.				