

## ICC-Profil Einstellungen / ICC Profile Settings

Epson Expression Photo XP-65			Papiere <b>Photolux</b> (10)	
Papier / Paper	Tinte / Ink	Medientyp / Media Type	Qualität / Quality	Profil / Profile
Cold Press Textured NaturalPRO 340	Coloration ED2	Epson Matte	Quality	XP65_CED_CPTNPro340.icc
Natural Fibre Mark II 265	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_CED2_NatFibreMK2.icc
StudioPRO2 Pearl Cool Tone 300	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_CED2_StudioPro2.icc
Portrait II Raster Cool Tone 275	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_CED2_Portrait2Raster.icc
FineArt Velvet 270	Coloration ED2	Epson Matte	Quality	24XL_CED2_FineartVelvet.icc
Expression Cool Tone 255	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_CED2_ExprCoolTone.icc
StudioSILVER Hochglanz 255	Coloration ED2	Epson Premium Glossy	Best Quality	24XL_CED2_StudioSilver.icc
StudioDUO Lustre 250	Coloration ED2	Epson Premium Semigloss	Best Quality	24XL_CED2_StudDuoLustre.icc
Professional Matte Paper 230	Coloration ED2	Epson Matte	Quality	24XL_CED2_ProfMatt230.icc
Professional Matte Paper 230 Duo	Coloration ED2	Epson Matte	Quality	24XL_CED2_ProMatt230duo.icc
In den Druckertreiber-Einstellungen die Option "Schweres Papier und Briefumschläge" mit der Einstellung "EIN" dauerhaft aktivieren.				